

WATERING MADE EASY SPRINKLER STATION LAYOUT GUIDE

USE THIS 2 PAGE GUIDE TO HELP DETERMINE WHERE TO LOCATE YOUR SPRINKLER STATION(S)

Use the twine included with this kit to help decide where to place the sprinklers.

PAGE 1 - SHOWS INFORMATION ABOUT THE SPRINKLER STATIONS

PAGE 2 - LAYOUT TIPS AND DIAGRAMS OF TYPICAL LAYOUTS




1-877-280-4485

WateringMadeEasy.com

FOR CUSTOMER SERVICE, PLEASE CALL 1-877-280-4485 OR EMAIL HELP@WATERINGMADEEASY.COM


THE ORIGINAL SPRINKLER STATION:

Comes with a 30 foot long piece of twine.
Sprays 35 foot radius.
Adjustable from 30 degrees to 300 degrees, or a full circle**.



THE SPRINKLER STATION JR.:


Comes with a 15 foot long piece of twine.
Mists a 15 foot radius.
Adjustable from 15-360 degrees**.



**MAX 340 DEGREE ANGLE RECOMMENDED TO AVOID GETTING SPRAYED WHEN TURNING ON AND OFF THE SPRINKLER AS WELL AS TO AVOID INTERFERENCE FROM THE HOSE.

THE SPRINKLER STATION SQUARED:

Comes with a 15 foot long piece of twine.
Adjusts to mist a 9 x 18 foot rectangle, a 4 x 15 rectangle or a 4 x 30 foot rectangle.



WATERING MADE EASY SPRINKLER STATION LAYOUT GUIDE

1. PLAN WHERE TO PLACE THE SPRINKLER STATION

Use the twine included with this kit to

help you determine where to locate the sprinkler(s).

- a. Have a friend hold one end of the twine where you think a sprinkler should be placed.
- b. Hold the other end of the twine and walk so the twine is tight. Where the twine covers should give you a general idea of the coverage of the sprinkler.

2. PLAN THE DIRECTION AND PATTERN OF SPRAY

- a. Plan to spray away from the hose connection.
- b. Original Sprinkler Station:

Plan how far around in each direction you would like the sprinkler to spray before reversing direction.

Sprinkler Station Jr.:

Plan how far around in each direction you would like the sprinkler to spray.

Sprinkler Station Squared:

Plan which rectangle you would like the sprinkler to spray.

9 x 18 foot rectangle

4 x 15 rectangle


4 x 30 foot rectangle

*** PLAN ONLY AT THIS STEP. Actually set the sprinkler during installation. The Installation Guide includes instructions for setting the spray pattern.**

** IMPORTANT REMINDERS

Plan access to connect your hose.

- a. Maximum 300 degree angle recommended for Original and Jr. for hose access to avoid getting sprayed when turning on and off the sprinkler and interference from the hose.
- b. Place the hose connection minimum of 1 foot from a fence or other boundary.



HELPFUL HINTS:

Three (3) Original Sprinkler Stations cover many lawns efficiently.


Use the Sprinkler Station Jr. and Sprinkler Station Squared to cover smaller areas while avoiding spraying driveways and walkways.

Use a splitter and 2 or three hoses at the same time to use more than one sprinkler, or use one hose and plug it into each sprinkler separately.

Use a shutoff timer to turn off the water after the correct amount of time and then roll the hose up at your convenience.


TYPICAL LAYOUTS:

2 ORIGINAL SPRINKLER STATIONS
1 SPRINKLER STATION JR.
2 SPRINKLER STATIONS SQUARED




3 ORIGINAL SPRINKLER STATIONS


2 ORIGINAL SPRINKLER STATIONS
1 SPRINKLER STATION SQUARED



3 ORIGINAL SPRINKLER STATIONS
2 SPRINKLER STATIONS SQUARED




2 ORIGINAL SPRINKLER STATIONS



1 SPRINKLER STATION JR.
2 SPRINKLER STATIONS SQUARED

1 ORIGINAL SPRINKLER STATION
3 SPRINKLER STATIONS SQUARED



2 ORIGINAL SPRINKLER STATIONS